





Before beginning installation, read these instructions carefully. This will simplify installation and ensure that the product is installed correctly and safely. Leave these instructions near the product after installation for future reference.

AU ENGLISH

WTG6520



MFL67792781 Rev.00\_020218

www.lg.com

## **TABLE OF CONTENTS**

This manual may contain images or content different from the model you purchased.

This manual is subject to revision by the manufacturer.

SAFETY INSTRUCTIONS	4
IMPORTANT SAFETY INSTRUCTIONS	
INSTALLATION	10
Parts	10
Accessories (Depending on Model)	10
Specifications	
Installation Place Requirements	12
Connecting the Supply Hose	13
Installing the Drain Hose	
Leveling the Appliance	
Assembling the Anti-Rat Cover (some models only)	17
OPERATION	18
Using the Appliance	
Sorting Laundry	
Adding Cleaning Products	
Control Panel	
Washing Programme	23
Option Programme	
Manual Washing	27
Special Functions	28
SMART FUNCTIONS	29
Using Smart Diagnosis™	
MAINTENANCE	30
Cleaning the Washing MachineCleaning the Water Inlet Filter	
Cleaning the Water Inlet Pilter	
Caution on Freezing During Winter	
Caddon on Freezing Duning Winter	
TROUBLESHOOTING	34
Diagnosing Problems	34
Error Messages	38

## **SAFETY INSTRUCTIONS**

The following safety guidelines are intended to prevent unforeseen risks or damage from unsafe or incorrect operation of the appliance.

The guidelines are separated into 'WARNING' and 'CAUTION' as described below.



This symbol is displayed to indicate matters and operations that can cause risk. Read the part with this symbol carefully and follow the instructions in order to avoid risk.



#### WARNING

This indicates that the failure to follow the instructions can cause serious injury or death.



### **▲** CAUTION

This indicates that the failure to follow the instructions can cause the minor injury or damage to the product.

#### IMPORTANT SAFETY INSTRUCTIONS



## WARNING

To reduce the risk of explosion, fire, death, electric shock, injury or scalding to persons when using this product, follow basic precautions, including the following:

## Children in the Household

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

#### Installation

- •Never attempt to operate the appliance if it is damaged, malfunctioning, partially disassembled, or has missing or broken parts, including a damaged cord or plug.
- •This appliance should only be transported by two or more people holding the appliance securely.
- •Tighten the drain hose at connecting ends to avoid separation.
- •If the power cord is damaged or the hole of the socket outlet is loose, do not use the power cord and contact an authorized service centre.
- Make sure the plug is completely pushed into the outlet.
- •Do not install the appliance in a damp and dusty place. Do not install or store the appliance in any outdoor area, or any area that is subject to weathering conditions such as direct sunlight, wind, or rain or temperatures below freezing.
- •Ventilation openings must not be obstructed by a carpet.
- •Do not plug the appliance into multiple socket outlets or extension power cable.
- •This appliance must be grounded (earthed via the power cord). In the event of malfunction or breakdown, grounding will reduce the risk of electric shock by providing a path of least resistance for electric current.
- •This appliance is equipped with a power cord having an equipment-grounding conductor (earthing pin) and a grounding power plug. The power plug must be plugged into an appropriate socket outlet that is installed and grounded in accordance with all local codes and ordinances.

- •Improper connection of the equipment-grounding conductor can result in risk of electric shock. Check with a qualified electrician or service personnel if you are in doubt as to whether the appliance is properly grounded.
- •Do not modify the power cord provided with the appliance.

## **Operation**

- Do not use a sharp object like drill or pin to penetrate, modify or disassemble the unit.
- •Keep the area underneath and around the appliance free of combustible materials such as lint, paper, rags, chemicals, etc.
- •Do not put animals, such as pets into the appliance.
- •Do not leave the appliance door open. Children may crawl inside the appliance, causing damage or injury.
- •Use a new hose or hose-set supplied with the appliance. Reusing old hoses can cause a water leak and subsequent property damage.
- •Turn off water taps to relieve pressure on hoses and valves and to minimize leakage if a break or rupture should occur. Check the condition of the fill hoses; they may need replacement after 5 years.
- •Never reach into the appliance while it is operating. Wait until the drum has completely stopped.
- •Do not put in, wash or dry articles that have been cleaned in, washed in, soaked in, or spotted with combustible or explosive substances (such as waxes, wax removers, oil, paint, gasoline, degreasers, drycleaning solvents, kerosene, petrol, spot removers, turpentine, vegetable oil, cooking oil, acetone, alcohol, etc.). Improper use can cause fire or explosion.

- •In case of flood, disconnect the power plug and contact the LG Electronics customer information centre.
- •Do not use or store flammable or combustible substances (ether, benzene, alcohol, chemical, LPG, combustible spray, insecticide, air freshener, cosmetics, etc.) near the appliance.
- •If there is a gas leakage (isobutane, propane, natural gas, etc.), do not touch the appliance or power plug and ventilate the area immediately.
- •If the drain hose or inlet hose is frozen during winter, use it only after thawing.
- •Keep all washing detergents, softener and bleach away from children.
- •Do not touch the power plug or the appliance controls with wet hands.
- Do not bend the power cable excessively or place a heavy object on it.
- •Do not put your hand, foot or anything under the washing machine while the washing machine is in operation.
- •Never insert hands or any items into the drum whilst it is still spinning.
- •Make sure that your Laundry floor drainage is working properly. If water is not drained properly, your floor may get flooded.
- •If, during spinning, opening the door does not stop the drum within about 15 seconds, immediately discontinue operating the appliance and contact your dealer or LG Electronics service centre.

- •Do not use a plug socket and wiring equipment for more than their rated capacity.
- •When the air temperature is high and the water temperature is low, condensation may occur and thus wet the floor.
- •Wipe off dirt or dust on the contacts of the power plug.
- •Under certain conditions hydrogen gas may be produced in a water heater that has not been used for two weeks or more. Hydrogen gas can be explosive under these circumstances. If the HOT water has not been used for two weeks or more, prevent the possibility of damage or injury by turning on all Hot water taps and allowing them to run for several minutes. Do this before using any electrical appliance which is connected to the HOT water system. This simple procedure will allow any built-up hydrogen gas to escape. Since the gas is flammable, do not smoke or use an open flame or appliance during this process.

#### **Maintenance**

- •Remove the power plug when you clean the appliance.
- •Securely plug the power plug in the socket outlet after completely removing any moisture and dust.
- •Do not spray water inside or outside the appliance to clean it.
- Never unplug the appliance by pulling on the power cable. Always grip the power plug firmly and pull straight out from the socket outlet.
- Only qualified service personnel from LG Electronics service centre should disassemble, repair, or modify the appliance.
   Contact an LG Electronics customer information centre if you move and install the appliance in a different location.

## **Disposal**


- •Before discarding an old appliance, unplug it. Cut off the cable directly behind the appliance to prevent misuse.
- •Dispose of all packaging materials (such as plastic bags and styrofoam) away from children. The packaging materials can cause suffocation.
- •Remove the door before disposing of or discarding this appliance to avoid the danger of children or small animals getting trapped inside.

## For Models with One Inlet Valve (some countries only)


•Do not connect to a hot water supply. Connect to cold water only.

## **INSTALLATION**

#### **Parts**



## **Accessories (Depending on Model)**



Appearance and specifications may change without notice to improve the quality of the product.


## **Specifications**

Model	WTG6520
Power Supply	220 - 240 V~, 50 Hz
Size	590 mm (W) x 606 mm (D) x 960 mm (H)
Product Weight	42.0 kg
Allowable water pressure	30 - 600 kPa
Max. capacity	6.5 kg

<sup>•</sup> Appearance and specifications may change without notice to improve the quality of the product.

# Installation Place Requirements

#### Location



**Level floor**: Allowable slope under the entire appliance is 1°.

**Power outlet**: Must be within 1.5 meters of either side of the location of the appliance.

 Do not overload the outlet with more than one appliance.

**Additional Clearance**: For the wall, 10 cm: rear/2 cm: right & left side.

 Do not place or store laundry products on top of the appliance at any time. These products may damage the finish or controls.

## **WARNING**

 The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.

## **Positioning**

- Install the appliance on a flat hard floor.
- Make sure that air circulation around the appliance is not impeded by carpets, rugs, etc.
- Never try to correct any unevenness in the floor with pieces of wood, cardboard or similar materials under the appliance.

- If it is impossible to avoid positioning the appliance next to a gas cooker or coal burning stove, an insulation (85x60 cm) covered with aluminum foil on the side facing the cooker or stove must be inserted between the two appliances.
- Do not install the appliance in rooms where freezing temperatures may occur. Frozen hoses may burst under pressure. The reliability of the electronic control unit may be impaired at temperatures below freezing point.
- Ensure that when the appliance is installed, it is easily accessible for an engineer in the event of a breakdown.
- If the appliance is delivered in winter and temperatures are below freezing, place the appliance at room temperature for a few hours before putting it into operation.

#### **WARNING**

 This appliance is not designed for maritime use or for use in mobile installations such as caravans, aircraft etc.

#### **Electrical Connection**


- Do not use an extension cord or double adapter.
- Always unplug the appliance and turn off the water supply after use.
- Connect the appliance to an earthed socket in accordance with current wiring regulations.
- The appliance must be positioned so that the plug is easily accessible.
- Repairs to the appliance must only be carried out by qualified personnel. Repairs carried out by inexperienced persons may cause injury or serious malfunctioning. Contact your localan authorised LG repairer.


## **Connecting the Supply Hose**

- Before connecting the water supply hose to the water tap, check the hose type and then choose the correct instruction.
- The water supply hose supplied may vary from country to country. Make sure to connect the blue supply hose to the COLD water tap, and the orange supply hose to the HOT water tap.
- Water supply pressure must be between 30 kPa and 600 kPa (0.3 6.0 kgf / cm²).
- Do not overtighten the water supply hose.
- If the water supply pressure is more than 600 kPa, a decompression device should be installed.
- Periodically check the condition of the hose and replace the hose if necessary.

## Checking the Rubber Seal on the Supply Hose

Two rubber seals are supplied with the water supply hoses. They are used for preventing water leaks. Make sure the connection to taps is sufficiently tight. Do not use mechanical devices such as multi grips to tighten the inlet hoses.





#### **Connecting Hose to Water Tap**


# Connecting Screw-Type Hose to Tap with Thread

Screw the hose connector onto the water supply tap.




# Connecting Screw-Type Hose to Tap Without Thread (Some countries only)


1 Loose the four fixing screws.




2 Remove the guide plate if the tap is too large to fit the adapter.



Push the adapter onto the end of the tap so that the rubber seal forms a watertight connection. Tighten the four fixing screws.




4 Push the supply hose vertically upwards so that the rubber seal within the hose can adhere completely to the tap and then tighten it by screwing it to the right.




## Connecting One Touch Type Hose to Tap Without Thread (Some countries only)

1 Unscrew the adapter ring plate and loose the four fixing screws.




2 Remove the guide plate if the tap is too large to fit the adapter.



Push the adapter onto the end of the tap so that the rubber seal forms a watertight connection. Tighten the four fixing screws and the adapter ring plate.



4 Pull the connector latch plate down, push the supply hose onto the adapter, and release the connector latch plate. Make sure the adapter locks into place.




#### NOTE

 After connecting the supply hose to the water tap, turn on the water tap to flush out foreign substances (dirt, sand, sawdust, and etc.) in the water lines. Let the water drain into a bucket, and check the water temperature.

# Connecting the Inlet Hoses to the Appliance

Attach the hot water line to the hot water inlet on the back of the washing machine. Attach the cold water line to the cold water inlet on the back of the washing machine.



#### NOTE

 After completing connection, if water leaks from the hose, repeat the same steps. Ensure that the rubber washers are fitted to both sides of the hose.


## **Installing the Drain Hose**

Before connecting the drain hose, check your drain hose model and choose the correct instruction.

# Pump Model (Australia and other countries)

- The drain hose should not be placed higher than 120 cm above the floor. Water in the washing machine may not drain or may drain slowly.
- Securing the drain hose correctly will protect the floor from damage in the event of water leakage.
- If the drain hose is too long, do not force it back into the washing machine. This will cause abnormal noise.
- When installing the drain hose to a sink, secure it tightly with string.






#### **NOTE**


 The discharge height should be approximately 0.9 - 1.2 m from the floor. Do not lay the drain hose on the ground, it must be connected to a laundry tub or stand pipe.

# Non-pump Model (some countries only)

1 Push the elbow hose toward the body of the washing machine.




2 To change the direction of the hose, pull out the elbow hose and change the direction. Repeat Step 1.




#### Positioning the Drain Hose


- The length of the drain hose should not exceed 3 m.
- Do not place the drain hose on a threshhold of 6 cm or more.



Make sure the drain hose is not kinked.




- The outlet of the drain hose should not be submerged in water.
- Make sure the drain hose is not kinked.



## Leveling the Appliance

If the floor is uneven, turn the adjustable feet as required (Do not insert pieces of wood etc. under the feet). Make sure that all four feet are stable and resting on the floor and then check that the appliance is perfectly level.



#### **Diagonal Check**

 When pushing down the edges of the appliance top plate diagonally, the appliance should not move up and down at all (Check both directions). If the appliance rocks when pushing the machine top plate diagonally, adjust the feet again.

#### **NOTE**

- Timber or suspended type flooring will contribute to excessive vibration and unbalance. Re enforcement or bracing of the timber floor may need to be considered to stop or reduce excessive noise and vibration.
- Do not install the washer on any elevated surface, stand or plinth as it can become unstable and fall causing serious injury and damage.
- If the washing machine is installed on a uneven, weak or tilted floor causing excessive vibration, spin failure or UE error can occur. It must be placed on a firm and level floor to prevent spin failure.


# Assembling the Anti-Rat Cover (some models only)

Insert the Anti-Rat cover to the assembling hole from the front or back of the washing machine.

Type 1



Type 2



## **Using the Appliance**

Before the first wash, select a washing programme (Cotton Wash, add a half load of detergent), allow the washing machine to wash without clothing. This will remove residue and water from the drum that may have been left during manufacturing.

- 1 Sort laundry and load items.
  - Sort laundry by fabric type, soil level, colour and load size as needed. Open the door and load items into the washing machine.



- 2 Add cleaning products and/or detergent and softener.
  - Add the proper amount of detergent to the detergent dispenser drawer. If desired, add bleach or fabric softener to the appropriate areas of the dispenser.
- 3 Turn on the washing machine.
  - Press the **Power** button to turn on the washing machine.





- 4 Choose the desired wash programme.
  - Press the **Program** button repeatedly until the desired programme is selected.



- 5 Begin programme.
  - Press the Start/Pause button to begin the programme. The washing machine will agitate briefly without water to measure the weight of the load. If the Start/Pause button is not pressed within 60 minutes, the washing machine will shut off and all settings will be lost.




- 6 End of programme.
  - When the programme is finished, a melody will sound. Immediately remove your clothing from the washing machine to reduce wrinkling.

#### NOTE

 The Auto Restart function allows the programme to restart by itself in case of power failure. It resumes from the stage where it stopped.

## **Sorting Laundry**

- 1 Look for the care label on your clothes.
  - This will tell you about the fabric content of your garment and how it should be washed.
  - Symbols on the care labels.



#### 2 Sorting laundry.

- To get the best results, sort clothes into loads that can be washed with the same wash cycle.
- Different fabrics need to be washed at varying temperatures and spin speeds.
- Wash two or more towels or knits together. If washed separately, laundry which absorbs a lot of water may not be washed well or abnormal spin-drying may occur due to an unbalanced load.
- Always sort dark colours from pale colours and whites. Wash separately as dye and lint transfer can occur causing discolouration of white and pale garments. Do not wash heavily soiled loads in this Machine.
- Soil (Heavy, Normal, Light):
   Separate clothes according to amount of soil
- Colour (White, Lights, Darks):
   Separate white fabrics from coloured fabrics.
- Lint (Lint producers, Collectors):
   Wash lint producers and lint collectors separately.

#### 3 Caring before loading.

- Combine large and small items in a load.
   Load large items first.
- Large items should not be more than half the total wash load. Do not wash single items. This may cause an unbalanced load. Add one or two similar items.
- Check all pockets to make sure that they are empty. Items such as nails, hair clips, matches, pens, coins and keys can damage both your washing machine and your clothes.



- Close zippers, hooks and strings to make sure that these items don't snag on other clothes
- Pre-treat dirt and stains by brushing a small amount of detergent dissolved water onto stains to help lift dirt.

## **A** CAUTION

- Do not wash or spin any item labeled or known to be water-proof or water-resistant, even if the product care label on the item permits machine washing. Failure to follow these instructions could result in severe damage to your laundry, your washing machine and/or property damage as a result of abnormal vibration of the washing machine.
  - Examples of water-proof or water-resistant items include certain mattress pads, mattress covers, rain gear, camping gear, skiing apparel, outdoor gear and similar items

# Adding Cleaning Products Detergent Dosage

- Detergent should be used according to the instruction of the detergent manufacturer and selected according to type, colour, soiling of the fabric and washing temperature.
- If too much detergent is used, too many suds can occur and this will result in poor washing results or cause heavy load to the motor.
- If you wish to use liquid detergent follow the guidelines provided by the detergent manufacturer.
- You can pour liquid detergent directly into the main detergent drawer if you are starting the cycle immediately.
- Do not use liquid detergent if you are using Time delay, or if you have selected Pre Wash, as the liquid may harden.
- If too many suds occur, reduce the detergent amount.
- Detergent usage may need to be adjusted for water temperature, water hardness, size and soil level of the load. For best results, avoid oversudsing.
- Refer to the label of the clothes, before choosing the detergent and water temperature.
- When using the washing machine, use designated detergent for each type of clothing only:
  - General powdered detergents for all types of
  - Powdered detergents for delicate fabric
  - Liquid detergents for all types of fabric or designated detergents only for wool
- For better washing performance and whitening, use detergent with the general powdered bleach.
- Detergent is flushed from the dispenser at the beginning of the cycle.


- Dilute liquid detergent with water and pour into the drum, start the cycle.
- Using liquid detergent without diluting, or leaving laundry for a long time after pouring diluted liquid detergent into the drum might cause damage, bleaching or discoloration of cloth

#### NOTE

- Do not let the detergent harden. Doing so may lead to blockages, poor rinse performance or odour
- Full load : According to manufacturer's recommendation.
- Part load: 3/4 of the normal amount
- Minimum load: 1/2 of full load

#### **Adding Detergent**

- Follow the detergent package directions.
   Using too little detergent is a common cause of laundry problems. Use more detergent if you have hard water, large loads, greasy or oily soils or lower water temperature.
- Soap flakes or granulated soap powders should not be used in your washing machine.
   When washing woolens, remember to use detergent suitable for washing woolens.



#### NOTE

• Too much detergent, bleach or softener may cause an overflow or a malfunction.

### **Adding Fabric Softener**

- Dilute fabric softener with water. Undiluted fabric softener may result in spots that look like oil stains.
- Measure and add the recommended amount of fabric softener into the compartment marked with this symbol ( )
  - Follow manufacturer's direction.
  - Fabric softener is automatically dispensed in the final rinse with an indication chime sound
  - If you select an extra rinse, you must add fabric softener manually when the indication chime sounds in the final rinse. This maximizes the fabric softener function.




- Do not overfill. The dispenser holds max 35 ml. Never add more than 35 ml. Overfilling can cause early dispensing of the fabric softener which could result in stained clothes. A cup with a pouring spout will help you avoid spilling and over filling.
- The effect of adding fabric softener may vary according to its viscosity. The sticker fabric softener makes its effect lower. For a sticky softener it is recommended that it be diluted with water, then be manually put during the time when the washer beeps several times before the final rinse. This function informing correct time dispense manually is optionally applied to some models. Please keep it in mind that fabric softener has to be diluted with water before dispensed and poured directly on clothes.

#### NOTE

- Do not mix with detergent or bleach.
- Never pour fabric softener directly on clothes.
   It may stain them.
- Do not stop the washer during the first spin for timely dispensing.
- Option washing is not designed to be used with fabric softener dispenser.

## Adding Liquid Bleach


- Check clothing care label for special instructions and separate the laundry to be bleached.
- Dilute liquid chlorine bleach.
- Measure the recommended amount of liquid bleach carefully following instructions on the bottle
- Before starting the washing machine, pour the measured amount of bleach directly into the bleach dispenser. Avoid splashing or overfilling. Powdered bleach should be mixed with water before being poured into the dispenser.



#### NOTE

- Never pour undiluted liquid bleach directly onto clothes or into the wash basket. This may cause change of color or damage the laundry.
- Do not pour powdered bleach into the bleach dispenser.

#### **Control Panel**



#### 1 Power Button

- Press the **Power** button to turn the washing machine on, or off if washing hasn't commenced.
- The appliance will automatically turn off once a certain time has passed after the wash has completed.

### 2 Start/Pause Button

- Press the Start/Pause button to start the wash cycle or pause the wash cycle.
- If a temporary stop of the wash cycle is needed, press the **Start/Pause** button.

#### **NOTE**

 If the washing machine is paused during a cycle for a few minutes, the cycle will be cancelled and any water remaining in the drum will be drained. A dr message will be shown in the display if this occurs as indicated in the TROUBLESHOOTING section of this manual.

#### 3 Program Button

- Programmes are available according to laundry type.
- Lamp will light up to indicate the selected programme.

#### 4 Option Button

Press buttons to select the desired options.

## 5 Display

- The display shows the settings, estimated time remaining, options, and status messages. When the washer is turned on, the default settings in the display will illuminate.
- The process lamp will remain prior to it beginning. The process lamp will blink during that process, and the lamp will then turn off when that process has completed.

## **Washing Programme**

Wash cycles are designed for the best wash performance for each type of load. Select the programme that best matches the load contents for maximum wash performance and fabric care. Press the **Program** button to select the desired programme. When you select a wash programme, the light for the corresponding wash programme will turn on.

#### Cotton Wash

Use this programme to wash cotton wash loads.

- This programme automatically selects the most appropriate conditions and completes the sequence in one operation.
- The built-in sensor detects the weight of the load and the ideal wash power and wash, rinse and spin times are set accordingly.
- If water is already in the tub, or putting wet laundry into the tub before starting increases the water level.
- Water level can be set low with lightweight bulky loads.
- Changes to water temperature (Hot Wash/ Cold Wash) and wash level are possible during operation.

#### Wool

Use this programme to wash delicate fabrics such as lingerie and woolens. Before washing, check the care label for the washing instructions.

- This programme uses a slow spin to extract water from laundry, so the laundry has more moisture than normal.
- Only cold water will be used for this programme as hot water may damage laundry.

#### NOTE

• Hang or lay flat to dry your delicates.

#### **Duvet**

Use this programme to wash a blanket or bedsheets with hand wash sign.

- Cashmere bedsheets, acrylic blanket, mixed spinning blanket, woolen blanket, infilling (polyester 101), and bed sheet might be damaged by floating. Please purchase a separate laundry net to wash.
- Separate bed clothes from general clothes.
   Not doing so might cause laundry to askew and may result in abnormal washing.
- Spin dry might take longer if bedsheets are lumped to a side.
- Never wash an electric blanket or carpets. It can cause damage to the machine.
- Please use a laundry net to soak and sink bedsheets that may float easily. it may damage the machine if the items float during the wash or spin.
- Regardless of size, we recommend twashing bedsheets individually. If two bedsheets with different materials are washed at the same time, it might cause a spin malfunction due to imbalance.

#### NOTE

How to put a blanket into the drum

Below this line



#### Silent

Use this programme to wash quietly in silent especially during late night and dawn.

- This programme has a longer washing time than the Normal programme.
- To reduce noise in spinning, this programme uses a slow spin to extract water from laundry, so the clothes will have more moisture than normal when the cycle has ended.

#### Pre Wash + Cotton

Use this programme to pretreat immediate stain without handwash. It is necessary for clothes which could smell bad without prompt laundry.

#### **Quick Wash**

Use this programme to wash lightly soiled clothes for a short time. This programme's recommended laundry amount is under 3 kg.

#### **Eco Cotton**

Use this programme to consume less water and electricity to wash normal clothes.

#### Information for Energy Test

Select the water temperature to suit wash cycles. Always follow garment manufacture's care label or instructions when washing.

- Set programme of Eco Cotton, Temp. Hot & Cold, Water Level 3, Wash 25min, Rinse 2, Spin High is for normally soiled load and testing in accordance or in conformity with AS/NZS 6400, and AS/NZS 2040, 2.
- The test results depend on water pressure, water hardness, water inlet temperature, room temperature, type and amount of load, degree of soiling utilized detergent, fluctuations in the main electricity supply and chosen additional options.
- For best washing results, we recommend dilute the detergent powder (drum type) in warm water and pour directly into tub.

## **Option Programme**

#### Soil Level

- This button allows you to select the strength of the wash action.
- There are 2 levels for Soil Level selection: Heavy and Light. This can be selected for any programme.
- If you do not select the Soil Level, it will be in the Normal state with the light turned off.
- · Adjustment can be made while washing.

#### Temp.

- If you want to to select water temperature, press the Temp. button to allow you to select: Cold → Warm (Hot & Cold) → Hot → Cold respectively.
- . Default setting is Cold.

#### Water Level

- Press the Water Level button to adjust water level. This may be required to avoid linting and unbalanced errors when the load is bulky but lightweight.
- It can be changed during operation.
- This machine detects the quantity of laundry automatically, then sets Water Level. It may be necessary to increase the water level manually when washing bulky light weight clothes.
- When you select a wash programme, the Water Level will be shown on the control panel.
- When Water Level is automatically detected, it may differ depending on the quantity of laundry even though the same Water Level is indicated on the control panel.

#### Wash

- Press the Wash button to change the wash time
- Adjusting the wash time setting will modify the cycle times and/or wash actions. Press the Wash button until the desired wash time is selected.

#### Rinse

Press the Rinse button to change the number of rinses

#### Spin

- Press the Spin button to change spin strength.
- Press Start/Pause button to indicate remaining time.

#### Delay

- You can set a time delay so that the washing machine will start automatically and finish after a specified time interval.
- 1 Press the Power button.
- 2 Select a washing programme.
- 3 Press the **Delay** button to set the required Delay ending time.
- 4 Press the Start/Pause button.

#### **NOTE**

- The delay time is the time to the end of the programme, not the start. The actual running time may vary due to water temperature, wash load and other factors.
- Time Delay reservation can be made up to 18 hours by 1-hour interval up to 3 - 12 hours and 2-hour interval for 12 - 18 hours. The Delay cannot be set for less than 3 hours.
- To cancel the Delay function, press Delay button repeatedly until the reservation is canceled or press the Power button to turn off and on power.

#### Soak

- Soak can be selected to wash heavily soiled clothes by soaking in water for some time to remove dirt and grime.

## **Manual Washing**

Rinse/Spin, Spin, Rinse, or Wash cycles can be set manually.

	Rinse, Spin	Spin only	Rinse only	Wash only
1	O or O  Press the <b>Power</b> button.			
2	Press the Rinse button.  Press the Rinse button.  Press the Rinse button.  Press the Rinse button.  Press the Wash button.			
3	Rinse and Spin are automatically selected.	Press the <b>Spin</b> button to adjust spin strength.	Press the <b>Spin</b> button until the spin function is canceled.	Rinse and Spin are automatically selected.
4	Press the <b>Rinse</b> or <b>Spin</b> buttons to adjust the number of rinses or the spin strength.		Press the <b>Rinse</b> button to adjust the number of rinses.	Press the <b>Rinse</b> and <b>Spin</b> buttons until the rinse and spin functions are canceled.
5	(MI)			
	Press the <b>Start/Pause</b> button.			

#### NOTE

- When a Wash, Wash/Rinse or Rinse only option is selected, the water will not be drained out after the wash is completed. If you wish to drain the water, select a Spin only cycle after the wash has completed.
- If Rinse only is selected, the process will start from the inlet water being supplied.
- If you do not select or change the Water Level, the water level will be set automatically. If the load is bulky but lightweight, the water level should be increased manually for better rinsing results.

## **Special Functions**

#### Child Lock

Use this option to disable the controls. This feature can prevent children from changing programmes or operating the appliance.

#### **Locking the Control Panel**

- Press and hold the Temp. and Rinse buttons simultaneously for 3 seconds.
- 2 '£' and the remaining time are alternatively shown on the display while they are locked.
  - When the Child Lock is set, all buttons are locked except the Power button.

#### NOTE

 Turning off the power will not reset the child lock function. You must deactivate child lock before you can access any other functions.

#### **Unlocking the Control Panel**

Press and hold the **Temp.** and **Rinse** buttons simultaneously for 3 seconds.

 A beeper will sound and the remaining time for the current programme will reappear on the display.


## SMART FUNCTIONS

## Using Smart Diagnosis™

# Smart Diagnosis™ Through the Customer Information Centre

Use this function if you need an accurate diagnosis by an LG Electronics customer information centre when the appliance malfunctions or fails. Use this function only to contact the service representative, not during normal operation.

- Press the Power button to turn on the washing machine. Do not press any other buttons.
- When instructed to do so by the call centre, place the mouthpiece of your phone close to the Smart Diagnosis™ icon.



- 3 Press and hold the Temp. button for 3 seconds.
- 4 Keep the phone in place until the tone transmission has finished. Time remaining for data transfer is displayed.
  - For best results, do not move the phone while the tones are being transmitted.
  - If the call centre agent is not able to get an accurate recording of the data, you may be asked to try again.

Once the countdown is over and the tones have stopped, resume your conversation with the call centre agent, who will then be able to assist you using the information transmitted for analysis.

#### NOTE

- The Smart Diagnosis<sup>™</sup> function depends on the local call quality.
- The communication performance will improve and you can receive better service if you use the home phone.
- If the Smart Diagnosis<sup>™</sup> data transfer is poor due to poor call quality, you may not receive the best Smart Diagnosis<sup>™</sup> service.

## **MAINTENANCE**

## **WARNING**

- Unplug the washing machine before cleaning to avoid the risk of electric shock. Failure to follow this warning may result in serious injury, fire, electric shock, or death.
- Never use harsh chemicals, abrasive cleaners, or solvents to clean the washing machine. They may damage the finish.

### Cleaning the Washing Machine

#### Care After Wash

- If you always use COLD water, we recommend that a WARM or HOT wash be used at regular intervals e.g. every 5th wash should be at least a WARM one.
- Turn off taps to prevent the chance of flooding should an inlet hose burst.
- · Always unplug the power cord after use.
- After the cycle is finished, wipe the door and the inside of the door seal to remove any moisture
- Leave the door open to dry the drum interior.
- Wipe the body of the washing machine with a dry cloth to remove any moisture.

## Cleaning the Exterior

Proper care of your washing machine can extend its life.

#### **Exterior:**

- · Immediately wipe off any spills.
- Wipe with a damp cloth.
- Do not press the surface or the display with sharp objects.

#### Dispenser Drawer:

Detergent and fabric softener may build up in the dispenser drawer. Remove the drawer and inserts and check for buildup once or twice a month.

#### **Tub Clean**

Tub Clean is a special function to help clean the inside of the washing machine. Perform this cycle regularly.

- A L cL indication on the display is just a reminder to run the Tub Clean function. It will appear after approximately 30 wash cycles. It can be temporarily overridden by continuing to select the desired wash programme.
- 1 Remove any clothing or items from the washing machine.
- Press the Power button.
- 3 Press the Program button to select Tub Clean. Water Level 6 is set automatically.
- Press the Start/Pause button.
- 5 10 minutes after the water has entered the machine, add the oxygenated bleach (about 300 ml).
- 6 Close the door.

## **A** CAUTION

 Children should be supervised if leaving the washing machine's door open.

#### NOTE


- · Do not use the detergent box.
- Before using this program, remove lint inside the lint filter.
- After using this program, remove dirt inside the lint filter.
- After finishing this program, open the washing machine door to remove irritant odor.
- Do not pour bleach into the tub directly. It might cause damage to the tub.
- Do not leave diluted oxygenated bleach inside the tub for a long time. It might rust the tub.
   Drain the remaining oxygenated water out.
- Use this program once a month.
- Do not use this program repeatedly.
- For models without a lint filter, the lint is discharged when the water drains during washing. Clean 1-2 times a month using the Tub Clean programme.

## Cleaning the Water Inlet Filter

- Turn off the supply taps to the machine if the washing machine is to be left for any length of time (e.g. holiday), especially if there is no floor drain (gully) in the immediate vicinity.
- '15' error message will be displayed on the control panel when water is not entering the detergent drawer.
- If water hardness level is high, or contains traces of lime deposit, the water inlet filter may become cloqued. It is therefore a good idea to clean it occasionally.
- Turn off the water tap and unscrew the water supply hose.



Clean the filter using a medium bristle tooth brush.



## Cleaning the Lint Filter (Optional)

The filter is an important part for an efficient washing performance result, so it needs special care from you. It is recommended that the filter be cleaned regularly.

#### **A** CAUTION


- Clean the lint filter after using it at least 2-3 times
- Do not drop the filter on the floor.
- Be careful not to have your nails caught in the filter when you handle the filter.
- The lint filter should be back into its original position after being washed to avoid damage to your laundry items. Do not operate the machine with the Lint filters removed.
- If the mesh hole of the lint filter is clogged, foreign objects in the laundry may not be filtered.
- Do not leave iron objects (such as clothes pins, hairpins, etc.), which rust easily in the lint filter

## Type 1


Push down on the release tab on the top of the filter cover and pull forward.



2 Open the lid and remove the lint.



3 Wash the filter with a soft brush.



4 Close the lid and then insert the lower part of the filter into the wash drum and press down then press the top part into position until you hear a clicking sound.



## Type 2

Push down on both sides of the release tabs of the filter cover and pull forward.



Open the lid, remove the lint and then wash out.





3 Close the lid and then insert the lower part of the filter into the wash drum and press the top part into position until you hear a click sound.




# Caution on Freezing During Winter

- When frozen, the product does not operate normally. Make sure to install the product where it will not freeze during winter.
- In case the product must be installed outside on a porch or in other outdoor conditions, make sure to check the following.

# How to Keep the Product from Freezing

 After closing the tap, disconnect the cold supply hose from the tap, and remove water while keeping the hose facing downwards.



## How to Handle Freezing

- When water supply problems occur, take the following measures.
  - Turn off the tap, and thaw out the tap and both connection areas of supply hose of the product using a hot water cloth.
  - Take out supply hose and immerse in warm water below 50–60 °C.



## **TROUBLESHOOTING**

The appliance is equipped with an automatic error-monitoring system to detect and diagnose problems at an early stage. If the appliance does not function properly or does not function at all, check the following before you call for service:

## **Diagnosing Problems**

Symptoms	Reason	Solution
Rattling and clanking noise	Foreign objects, such as keys, coins, or safety pins may be in the drum.	Stop the washing machine, check drum for foreign objects. If noise continues after washing machine is restarted, call for service.
Thumping sound	Heavy wash loads may produce a thumping sound. This is usually normal.	If sound continues, washing machine is probably out of balance. Stop and redistribute the wash load.
	Wash load may be out of balance.	Pause the cycle and redistribute the load after the door unlocks.
	Packaging materials were not removed.	Remove packing materials
	Wash load may be unevenly distributed in the drum.	Pause the cycle and redistribute the load after the door unlocks.
Vibrating noise	Not all leveling feet are resting firmly and evenly on the floor.	See Leveling the Appliance in the Installation section.
	Floor not rigid enough.	Make sure that the floor is solid and does not flex. See the Installation Place Requirements section.
Poor stain removal	Proper options not selected.	Heavier soils and tougher stains may require extra cleaning power. Select the Soak feature to boost the cleaning power of the selected cycle.
	Previously set stains.	Articles that have previously been washed may have stains that have been set. These stains may be difficult to remove and may require hand washing or pretreating to aid in stain removal.

Symptoms	Reason	Solution
	Bleach or softener dispensed too soon.	Dispenser compartment is overfilled causing bleach or softener to dispense immediately. ALWAYS measure bleach to prevent overfilling.     Close the dispenser drawer slowly.
Staining	Bleach or softener was added directly to the wash load in the drum.	<ul> <li>Always use the dispensers to ensure that laundry products are properly dispensed at the right time in the cycle.</li> </ul>
	Clothes were not properly sorted.	<ul> <li>Always wash dark colours separately from light colours and whites to prevent discoloration.</li> <li>Never wash heavily soiled items with lightly soiled items.</li> </ul>
	Supply hose connection is loose at tap or washing machine.	Check hoses for leaks, cracks and splits.     Tighten hose connections.
	House drain pipes are clogged.	The washing machine pumps out water very rapidly. Check for water backing up out of the drain pipe during drain. If water is seen coming out of the drain, check for proper drain hose installation and check for restrictions in the drain. Contact a plumber to repair the drain pipe.
Water leaking	Drain hose has come out of drain or is not inserted far enough.	Tie drain hose to supply hose or standpipe to prevent it from coming out during drain. For smaller drain pipes, insert the drain hose into the pipe as far as the drain hose flange. For larger drain pipes, insert the drain hose into the pipe 2.5 - 5 cm past the flange.
	A large item such as a pillow or blanket is above the top of the drum.	Stop the washing machine and check the load. Make sure the load does not crest above the top edge of the drum and is fully submerged in the water.

Symptoms	Reason	Solution
	Control panel has powered off due to inactivity.	This is normal. Press the <b>Power</b> button to turn the washing machine back on.
	Washing machine is unplugged.	Make sure the power cord is plugged securely into a working outlet.
	Water supply is turned off.	Turn both hot and cold taps fully on.
	Controls are not set properly.	Make sure the cycle was set correctly, close the door and press the <b>Start/Pause</b> button.
	Door is open.	Close the door and make sure that nothing is caught under the door preventing it from closing completely.
Washing machine will not operate	Circuit breaker/fuse is tripped/blown.	Check house circuit breakers/fuses. Replace fuses or reset breaker. The washing machine should be on a dedicated circuit. The washing machine will resume the cycle from where it stopped once power is restored.
	Control needs to be reset.	Press the <b>Power</b> button, then reselect the desired cycle and press the <b>Start/ Pause</b> button.
	Start/Pause was not pressed after a cycle was set.	Press the Power button then reselect the desired cycle and press the Start/Pause button. The washing machine will shut off if the Start/Pause button is not pressed within 60 minutes.
	Extremely low water pressure.	Check another tap in the house to make sure that household water pressure is adequate.
	Washing machine is too cold.	If the washing machine has been exposed to temperatures below freezing for an extended period of time, allow it to warm up before pressing the <b>Power</b> button.
	Washing machine is heating the water or making vapour. (some models only)	The washing machine drum may stop operating temporarily during certain cycles, while water is safely heated to a set temperature.

Symptoms	Reason	Solution
Washing machine	Filter clogged.	Make sure the inlet filters on the fill valves are not clogged.
	Supply hoses may be kinked.	Check that supply hoses are not kinked or clogged.
not filling properly	Insufficient water supply.	Make sure that both hot and cold water taps are turned on all the way.
	Hot and cold supply hoses are reversed.	Check supply hose connections.
	Kinked drain hose.	Ensure that the drain hose is not kinked.
Washing machine will not drain water	Drain located higher than 1.2 m above the floor.	Make sure that the drain hose is no higher than 1.2 m above the bottom of the washing machine.
Wrinkling	Washing machine not unloaded promptly.	Always remove items from the washing machine as soon as the cycle is completed.
	Washing machine overloaded.	The washing machine can be fully loaded, but the drum should not be tightly packed with items. The door of the washing machine should close easily.
	Hot and cold water supply hoses are reversed.	Hot water rinse can set wrinkles in garments. Check the supply hose connections.
Incomplete or no dispensing of detergent	Too much detergent used.	Follow the guidelines provided by the detergent manufacturer.
Musty or mildewy odor in washing machine	Inside of drum was not cleaned properly.	Run the Tub clean cycle regularly.
Cycle time is longer than usual	The load is too small.	Add more items to allow the washing machine to balance the loads.
	Heavy articles are mixed with lighter items.	Always try to wash articles of somewhat similar weight to allow the washing machine to evenly distribute the weight of the load for spinning.
	The load is out of balance.	Manually redistribute the load if articles have become tangled.

## **Error Messages**

Symptoms	Reason	Solution
dE	The door is not closed properly.	Close the door completely. If the error code is not released, call for service.
d'L	Door lock switch error.	Check nothing is caught under the door, including shipping materials or lothing. Close the door completely. If the error code is not released, call for service.
dr	Special Drain Feature.	If the washing machine is paused during a cycle for a few minutes, the cycle will be cancelled and any water remaining in the drum will be drained.
	Water supply taps are not fully open.	Fully open tap.
	Water line hoses are kinked, pinched, or crushed.	Straighten the hose(s).
	Water inlet filters are clogged.	Clean the inlet filters.
	Water supply pressure to tap or house is too low or very high.	Contact a plumber to have the water lines repaired.
	Water supply connected with leaklimiting hoses.	Do not use leak limiting hoses.
L E1	Foreign objects, such as coins, pins, clips, etc., caught between the wash plate and the inner basket.	Turn off the washing machine and then press the <b>Power</b> button. Press the <b>Spin</b> button without selecting a cycle to drain and spin the load. When the spin is complete, remove the clothes and then find and remove any objects caught in the wash plate.
OE DE	Drain hose is kinked, pinched, or clogged.	Straighten the hose(s).
	Drain discharge is more than 1.2 m above bottom of washing machine.	Adjust or repair drain. Maximum drain height is 1.2 m.

Symptoms	Reason	Solution	
	UE rebalancing operation was not successful.	The automatic attempt to rebalance the load was not successful. The cycle has been paused to allow the load to be manually adjusted.	
LIE	The load is too small.	Add more items to allow the washing machine to balance the loads.	
	Heavy articles are mixed with lighter items.	Wash articles of somewhat similar weight.	
	The load is out of balance.	Manually redistribute the load if articles have become tangled.	
ŁE]	Control error.	Unplug the washing machine and wait 60 seconds. Reconnect power and try again. If the error code is not released, call for service.	
FE	Water level is too high due to a faulty water valve.	Close the water taps, unplug the washing machine, and call for service.	
PE	The water level sensor is not working correctly.	Close the water taps, unplug the washing machine, and call for service.	
LE	A motor error has occurred.	Allow the washing machine to stand for 30 minutes and then restart the cycle. If the error code is not released, call for service.	
RE	Clutch error.	Unplug the washing machine and call for service.	
EcL	Tub clean Alarm.	Run the Tub Clean programme.	
<i>E3</i>	Sensing malfunction.	Manually redistribute the load if articles have become tangled.	
	Motor's revolution is too low.	Unplug the washing machine and	
	Contact-point of Connector is defective.	wait 60 seconds. Reconnect power and try again.  • Call for service.	
EL	CL is not an error. This prevents children from changing cycles or operating the appliance.	To deactivate, press the <b>Temp.</b> and <b>Rinse</b> buttons simultaneously for 3 seconds.	

